




PLEASE KEEP ME WITH YOUR PROOF OF PURCHASE FOR FUTURE REFERENCE.



ASSEMBLY INSTRUCTIONS
KINGSTON 120 ROUND TABLE
(60721162)



For replacement or lost spare parts please go to <http://faq.hartmanuk.co.uk/spares/>
Should you have any queries about your furniture your first point of contact should be the retailer from whom you purchased your product.

PLEASE KEEP ME WITH YOUR PROOF OF PURCHASE FOR FUTURE REFERENCE.

ATTENTION:










1. Please read these instructions carefully before assembly
2. Aluminium is soft metal and over tightening may strip thread or break the part
3. DO NOT use power tools however you will require a 14mm spanner and flat head screw driver to assemble product.
4. Please allow 30 minutes for assembly.
5. Although assembly only requires 1 person it is advised that a second person be present to help turn the table over and into position when fully assembled.

ASSEMBLY STEPS:

1. **LOOSELY** attach the 4 centre plates (B) to the legs (C). Please note that the shaped end of each plate fits to the leg at each corner, secure using big flat washers (E), big lock washers (F) and nuts (G).
2. Turn the table top (A) upside down on a soft clean surface.
3. Using flat head screw driver screw the bolts (D) into the table top.
4. Attach the 4 legs (C) to the table top at the points where the bolts (D) have been placed. Then slide big flat washers (E), big lock washers (F), and nuts (G) on to the bolt. **DO NOT TIGHTEN THE NUTS AT THIS STAGE.**
5. Tighten all the bolts (D) and nuts (G) with the 14mm spanner one by one being careful not to over tighten any, as this will cause the thread to become damaged.
6. Place nut caps (H) on all visible nuts (G)
7. Turn the table onto its legs and use the adjuster feet (I) to level the table.

For more information regarding maintenance of your furniture please visit

http://www.hartmanuk.co.uk/after_care_videos.html

Component's				Fixings					
Parts List	Parts Picture	Description	Q'ty	Part No.	Parts list	Parts Picture	Description	Q'ty	Part no.
A		Table Top	1	60778162A	D	 (M8*40)	Bolt	4	1000162
B		Centre plate	4	60778162B	E		Big Flat Washer	12	1001162
C		Table Leg	4	60778162C	F		Big Lock Washer	12	1002162
					G		Nut	12	1003162
					H		Nut Cap	12	1004162
!! Please Note screw in feet (I) are already inserted in the bottom of the legs (C)					I		Screw in feet	4	1005162

For replacement or lost spare parts please go to <http://faq.hartmanuk.co.uk/spares/>

Should you have any queries about your furniture your first point of contact should be the retailer from whom you purchased your product.