




# Assembly Instructions



## **OAKWOOD RECTANGULAR TABLE**

## **IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY**

### **WARNINGS**


- Dispose of all packing carefully and responsibly.
- Place product on an even surface prior to using.
- Suitable for Domestic Garden use only.
- Children should not be left alone in situ with product. Please prevent children climbing onto non-seating areas of the product.
- Frequently check any damage to the product including the underside and tighten fixings where required.
- Please use appropriate furniture covers when not in use. With all product, it must be protected from the elements. If it is left in sunlight without covering, it will begin to fade in colour. Please make sure to remove all debris / dirt before covering.
- In order to prolong the life of your product, we recommend it be stored in a dry and protected area during off season periods.
- Do not use a pressure washer to clean your product.
- Check you have all the components and tools listed before assembly.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts are a choking hazard if swallowed.
- Make sure you have enough space to lay out the parts before starting.
- Do not stand or put weight on the parts during assembly, this could cause damage.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- This product is manufactured from toughened safety glass. In the unlikely event that the glass fails it will break into a large number of small fragments that may be spread over a wide area. This is a feature of toughened glass, designed to remove the risk of injury from glass breaking into large shards.
- If the glass is chipped or broken, stop using the product.
- Do not place very hot or very cold items on the glass.
- Do not use the glass as chopping surface. Do not strike the glass with hard or pointed items.
- Do not sit or stand on the table.
- To prevent scratches, avoid sharp objects on surface and do not place hot items directly onto the surface.
- Avoid "ring marks" and scratches by using coasters, mats or runners.

### **CARE/CLEANING**

- Do not use any abrasive substances which may scratch the surface.
- Remove all debris / dirt with soft bristle brush / cloth, use a clean cloth to wipe clean any problem areas. For thorough cleaning, use a mild soap and warm water, apply with a micro fibre cloth (no abrasive materials), wipe clean and let dry.
- Do not use any abrasive substances which may scratch the surface.
- Use a high-quality non-streaking window / glass cleaner. Lightly wipe clean with a towel - terry towel is recommended as it is lint free.
- Use a clean soapy damp cloth and wipe down the surfaces - leave to fully dry before storing.


# Fixings List

① x6



Bolt: M6x40mm

② x6



Washer: M6

③ x6




Plastic Washer: M6

④ x1




Allen Key


# Parts List




Ⓐ x1



Ⓑ x1




Ⓒ x1




Ⓓ x1


DO NOT USE POWER TOOLS





Step 1



Step 2




Step 3





# Assembly Instructions



## **OAKWOOD LONG STOOL**

## **IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY**


### **WARNINGS**

- Dispose of all packing carefully and responsibly.
- Place product on an even surface prior to using.
- Suitable for Domestic Garden use only.
- Children should not be left alone in situ with product. Please prevent children climbing onto non-seating areas of the product.
- Frequently check any damage to the product including the underside and tighten fixings where required.
- Please use appropriate furniture covers when not in use. With all product, it must be protected from the elements. If it is left in sunlight without covering, it will begin to fade in colour. Please make sure to remove all debris / dirt before covering.
- In order to prolong the life of your product, we recommend it be stored in a dry and protected area during off season periods.
- Do not use a pressure washer to clean your product.
- Check you have all the components and tools listed before assembly.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts are a choking hazard if swallowed.
- Make sure you have enough space to lay out the parts before starting.
- Do not stand or put weight on the parts during assembly, this could cause damage.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- This product is manufactured from toughened safety glass. In the unlikely event that the glass fails it will break into a large number of small fragments that may be spread over a wide area. This is a feature of toughened glass, designed to remove the risk of injury from glass breaking into large shards.
- If the glass is chipped or broken, stop using the product.
- Do not place very hot or very cold items on the glass.
- Do not use the glass as chopping surface. Do not strike the glass with hard or pointed items.
- Do not sit or stand on the table.
- To prevent scratches, avoid sharp objects on surface and do not place hot items directly onto the surface.
- Avoid "ring marks" and scratches by using coasters, mats or runners.


### **CARE/CLEANING**

- Do not use any abrasive substances which may scratch the surface.
- Remove all debris / dirt with soft bristle brush / cloth, use a clean cloth to wipe clean any problem areas. For thorough cleaning, use a mild soap and warm water, apply with a micro fibre cloth (no abrasive materials), wipe clean and let dry.
- Do not use any abrasive substances which may scratch the surface.
- Use a high-quality non-streaking window / glass cleaner. Lightly wipe clean with a towel - terry towel is recommended as it is lint free.
- Use a clean soapy damp cloth and wipe down the surfaces - leave to fully dry before storing.



# Parts List



**L x 1**




**M x 1**





# Assembly Instructions



## **OAKWOOD CORNER CHAIR**

## **IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY**


### **WARNINGS**

- Dispose of all packing carefully and responsibly.
- Place product on an even surface prior to using.
- Suitable for Domestic Garden use only.
- Children should not be left alone in situ with product. Please prevent children climbing onto non-seating areas of the product.
- Frequently check any damage to the product including the underside and tighten fixings where required.
- Please use appropriate furniture covers when not in use. With all product, it must be protected from the elements. If it is left in sunlight without covering, it will begin to fade in colour. Please make sure to remove all debris / dirt before covering.
- In order to prolong the life of your product, we recommend it be stored in a dry and protected area during off season periods.
- Do not use a pressure washer to clean your product.
- Check you have all the components and tools listed before assembly.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts are a choking hazard if swallowed.
- Make sure you have enough space to lay out the parts before starting.
- Do not stand or put weight on the parts during assembly, this could cause damage.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- This product is manufactured from toughened safety glass. In the unlikely event that the glass fails it will break into a large number of small fragments that may be spread over a wide area. This is a feature of toughened glass, designed to remove the risk of injury from glass breaking into large shards.
- If the glass is chipped or broken, stop using the product.
- Do not place very hot or very cold items on the glass.
- Do not use the glass as chopping surface. Do not strike the glass with hard or pointed items.
- Do not sit or stand on the table.
- To prevent scratches, avoid sharp objects on surface and do not place hot items directly onto the surface.
- Avoid "ring marks" and scratches by using coasters, mats or runners.


### **CARE/CLEANING**

- Do not use any abrasive substances which may scratch the surface.
- Remove all debris / dirt with soft bristle brush / cloth, use a clean cloth to wipe clean any problem areas. For thorough cleaning, use a mild soap and warm water, apply with a micro fibre cloth (no abrasive materials), wipe clean and let dry.
- Do not use any abrasive substances which may scratch the surface.
- Use a high-quality non-streaking window / glass cleaner. Lightly wipe clean with a towel - terry towel is recommended as it is lint free.
- Use a clean soapy damp cloth and wipe down the surfaces - leave to fully dry before storing.


# Parts List




**B**x 1



**H**x 1





**I**x 1





**J**x 1



**E**x 4




**UNDERSIDE**  
Connect the bottom of Chairs  
by Clips **E** if necessary.





# Assembly Instructions



## **OAKWOOD SOFA 2 LEFT**

## **IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY**


### **WARNINGS**

- Dispose of all packing carefully and responsibly.
- Place product on an even surface prior to using.
- Suitable for Domestic Garden use only.
- Children should not be left alone in situ with product. Please prevent children climbing onto non-seating areas of the product.
- Frequently check any damage to the product including the underside and tighten fixings where required.
- Please use appropriate furniture covers when not in use. With all product, it must be protected from the elements. If it is left in sunlight without covering, it will begin to fade in colour. Please make sure to remove all debris / dirt before covering.
- In order to prolong the life of your product, we recommend it be stored in a dry and protected area during off season periods.
- Do not use a pressure washer to clean your product.
- Check you have all the components and tools listed before assembly.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts are a choking hazard if swallowed.
- Make sure you have enough space to lay out the parts before starting.
- Do not stand or put weight on the parts during assembly, this could cause damage.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- This product is manufactured from toughened safety glass. In the unlikely event that the glass fails it will break into a large number of small fragments that may be spread over a wide area. This is a feature of toughened glass, designed to remove the risk of injury from glass breaking into large shards.
- If the glass is chipped or broken, stop using the product.
- Do not place very hot or very cold items on the glass.
- Do not use the glass as chopping surface. Do not strike the glass with hard or pointed items.
- Do not sit or stand on the table.
- To prevent scratches, avoid sharp objects on surface and do not place hot items directly onto the surface.
- Avoid "ring marks" and scratches by using coasters, mats or runners.


### **CARE/CLEANING**

- Do not use any abrasive substances which may scratch the surface.
- Remove all debris / dirt with soft bristle brush / cloth, use a clean cloth to wipe clean any problem areas. For thorough cleaning, use a mild soap and warm water, apply with a micro fibre cloth (no abrasive materials), wipe clean and let dry.
- Do not use any abrasive substances which may scratch the surface.
- Use a high-quality non-streaking window / glass cleaner. Lightly wipe clean with a towel - terry towel is recommended as it is lint free.
- Use a clean soapy damp cloth and wipe down the surfaces - leave to fully dry before storing.


# Parts List





**D** x 1





**F** x 2



**G** x 1




**UNDERSIDE**  
Connect the bottom of Chairs  
by Clips **E** if necessary.





# Assembly Instructions



## **OAKWOOD SOFA 2 RIGHT**

## **IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY**


### **WARNINGS**

- Dispose of all packing carefully and responsibly.
- Place product on an even surface prior to using.
- Suitable for Domestic Garden use only.
- Children should not be left alone in situ with product. Please prevent children climbing onto non-seating areas of the product.
- Frequently check any damage to the product including the underside and tighten fixings where required.
- Please use appropriate furniture covers when not in use. With all product, it must be protected from the elements. If it is left in sunlight without covering, it will begin to fade in colour. Please make sure to remove all debris / dirt before covering.
- In order to prolong the life of your product, we recommend it be stored in a dry and protected area during off season periods.
- Do not use a pressure washer to clean your product.
- Check you have all the components and tools listed before assembly.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts are a choking hazard if swallowed.
- Make sure you have enough space to lay out the parts before starting.
- Do not stand or put weight on the parts during assembly, this could cause damage.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- This product is manufactured from toughened safety glass. In the unlikely event that the glass fails it will break into a large number of small fragments that may be spread over a wide area. This is a feature of toughened glass, designed to remove the risk of injury from glass breaking into large shards.
- If the glass is chipped or broken, stop using the product.
- Do not place very hot or very cold items on the glass.
- Do not use the glass as chopping surface. Do not strike the glass with hard or pointed items.
- Do not sit or stand on the table.
- To prevent scratches, avoid sharp objects on surface and do not place hot items directly onto the surface.
- Avoid "ring marks" and scratches by using coasters, mats or runners.


### **CARE/CLEANING**

- Do not use any abrasive substances which may scratch the surface.
- Remove all debris / dirt with soft bristle brush / cloth, use a clean cloth to wipe clean any problem areas. For thorough cleaning, use a mild soap and warm water, apply with a micro fibre cloth (no abrasive materials), wipe clean and let dry.
- Do not use any abrasive substances which may scratch the surface.
- Use a high-quality non-streaking window / glass cleaner. Lightly wipe clean with a towel - terry towel is recommended as it is lint free.
- Use a clean soapy damp cloth and wipe down the surfaces - leave to fully dry before storing.


# Parts List





**A x 1**





**F x 2**



**G x 1**




**UNDERSIDE**  
Connect the bottom of Chairs  
by Clips **E** if necessary.





# Assembly Instructions



## **OAKWOOD SINGLE CHAIR**

## **IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY**

### **WARNINGS**

- Dispose of all packing carefully and responsibly.
- Place product on an even surface prior to using.
- Suitable for Domestic Garden use only.
- Children should not be left alone in situ with product. Please prevent children climbing onto non-seating areas of the product.
- Frequently check any damage to the product including the underside and tighten fixings where required.
- Please use appropriate furniture covers when not in use. With all product, it must be protected from the elements. If it is left in sunlight without covering, it will begin to fade in colour. Please make sure to remove all debris / dirt before covering.
- In order to prolong the life of your product, we recommend it be stored in a dry and protected area during off season periods.
- Do not use a pressure washer to clean your product.
- Check you have all the components and tools listed before assembly.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts are a choking hazard if swallowed.
- Make sure you have enough space to lay out the parts before starting.
- Do not stand or put weight on the parts during assembly, this could cause damage.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- This product is manufactured from toughened safety glass. In the unlikely event that the glass fails it will break into a large number of small fragments that may be spread over a wide area. This is a feature of toughened glass, designed to remove the risk of injury from glass breaking into large shards.
- If the glass is chipped or broken, stop using the product.
- Do not place very hot or very cold items on the glass.
- Do not use the glass as chopping surface. Do not strike the glass with hard or pointed items.
- Do not sit or stand on the table.
- To prevent scratches, avoid sharp objects on surface and do not place hot items directly onto the surface.
- Avoid "ring marks" and scratches by using coasters, mats or runners.


### **CARE/CLEANING**

- Do not use any abrasive substances which may scratch the surface.
- Remove all debris / dirt with soft bristle brush / cloth, use a clean cloth to wipe clean any problem areas. For thorough cleaning, use a mild soap and warm water, apply with a micro fibre cloth (no abrasive materials), wipe clean and let dry.
- Do not use any abrasive substances which may scratch the surface.
- Use a high-quality non-streaking window / glass cleaner. Lightly wipe clean with a towel - terry towel is recommended as it is lint free.
- Use a clean soapy damp cloth and wipe down the surfaces - leave to fully dry before storing.


# Parts List



**C**x 1





**F**x 1





**K**x 1



**E**x 2




**UNDERSIDE**  
Connect the bottom of Chairs  
by Clips **E** if necessary.





# Assembly Instructions



## **OAKWOOD SHORT STOOL**

## **IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY**


### **WARNINGS**

- Dispose of all packing carefully and responsibly.
- Place product on an even surface prior to using.
- Suitable for Domestic Garden use only.
- Children should not be left alone in situ with product. Please prevent children climbing onto non-seating areas of the product.
- Frequently check any damage to the product including the underside and tighten fixings where required.
- Please use appropriate furniture covers when not in use. With all product, it must be protected from the elements. If it is left in sunlight without covering, it will begin to fade in colour. Please make sure to remove all debris / dirt before covering.
- In order to prolong the life of your product, we recommend it be stored in a dry and protected area during off season periods.
- Do not use a pressure washer to clean your product.
- Check you have all the components and tools listed before assembly.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts are a choking hazard if swallowed.
- Make sure you have enough space to lay out the parts before starting.
- Do not stand or put weight on the parts during assembly, this could cause damage.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- This product is manufactured from toughened safety glass. In the unlikely event that the glass fails it will break into a large number of small fragments that may be spread over a wide area. This is a feature of toughened glass, designed to remove the risk of injury from glass breaking into large shards.
- If the glass is chipped or broken, stop using the product.
- Do not place very hot or very cold items on the glass.
- Do not use the glass as chopping surface. Do not strike the glass with hard or pointed items.
- Do not sit or stand on the table.
- To prevent scratches, avoid sharp objects on surface and do not place hot items directly onto the surface.
- Avoid "ring marks" and scratches by using coasters, mats or runners.


### **CARE/CLEANING**

- Do not use any abrasive substances which may scratch the surface.
- Remove all debris / dirt with soft bristle brush / cloth, use a clean cloth to wipe clean any problem areas. For thorough cleaning, use a mild soap and warm water, apply with a micro fibre cloth (no abrasive materials), wipe clean and let dry.
- Do not use any abrasive substances which may scratch the surface.
- Use a high-quality non-streaking window / glass cleaner. Lightly wipe clean with a towel - terry towel is recommended as it is lint free.
- Use a clean soapy damp cloth and wipe down the surfaces - leave to fully dry before storing.

# Parts List



**N x 1**



**O x 1**

